

ENGLISH

D-100/H-100

V1

Ordercode: D6547D/D6547H

D-100/H-100

Table of contents

Warning	
WarningUnpacking Instructions	
Safety Instructions	
Operating Determinations	(
Operating Determinations	
Claims	
Description of the device	
Installation	
Installation	
Connecting To a Power Supply	
9 • • • • • • • • • • • • • • • • • • •	
Troubleshooting	
-	
Product Specification	
· · · · · · · · · · · · · · · · · · ·	
Dimensions	3
Notes	ç



Warning



For your own safety, please read this user manual carefully before your initial start-up!




Unpacking Instructions

Immediately upon receiving this product, carefully unpack the carton and check the contents to ensure that all parts are present, and have been received in good condition. Notify the dealer immediately and retain packing material for inspection if any parts appear damaged from shipping or the carton itself shows signs of mishandling. Save the carton and all packing materials. In the event that a fixture must be returned to the factory, it is important that the fixture be returned in the original factory box and packing.

Your shipment includes:

- DAP Audio D6547D (Driver) or D6547H (Horn)
- User manual





CAUTION!

Keep this device away from rain and moisture!
Unplug mains lead before opening the housing!



Safety Instructions

Every person involved with the installation, operation and maintenance of this system has to:

- be qualified
- follow the instructions of this manual



CAUTION! Be careful with your operations.

With a dangerous voltage you can suffer a dangerous electric shock when touching the wires!



Before you initial start-up, please make sure that there is no damage caused by transportation. Should there be any, consult your dealer and do not use the system.

To maintain perfect condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this manual.

Please consider that damages caused by manual modifications to the system are not subject to warranty.

This system contains no user-serviceable parts. Refer servicing to qualified technicians only.



IMPORTANT:

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorized modification to the system.

- Never remove warning or informative labels from the unit.
- Never leave any cables lying around.
- Do not open the device and do not modify the device.
- Do not set the input signal level higher than required to drive the equipment to full output.
- Avoid flames and do not put close to flammable liquids or gases.
- Make sure you do not use the wrong kind of cables or defective cables.
- Extreme frequency boosts in connection with a high input signal level may lead to overdriving your equipment. Should this occur, it is necessary to reduce the input signal level.
- If system is dropped or struck, disconnect the power supply immediately. Have a qualified engineer inspect for safety before operating.
- If the system has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation water might damage your system. Leave the system switched off until it has reached room temperature.
- If your Dap Audio device fails to work properly, discontinue use immediately. Pack the unit securely (preferably in the original packing material), and return it to your Dap Audio dealer for service.
- Repairs, servicing and electric connection must be carried out by a qualified technician.
- Keep this manual for future reference.
- Clean only with dry cloth.
- Take care of your speaker wires, they should be free of damage. Damaged speaker wires might result in poor sound quality and can damage amplifiers.
- No main power shall be connected to the loudspeakers; doing so will damage the speaker.
- This device should only be serviced by qualified personnel. If not warranty might be void.
- Use cable of the right gauge, certainly for long runs.
- Use cables with clear color indication and maintain polarity throughout the whole system.
- Avoid loud feedback from microphones, this can damage your speaker.
- Please check the units condition after unpacking. If the outside of the carton box has been damaged, inform your shipper immediately.

Operating Determinations

If this system is operated in any other way, than the one described in this manual, the product may suffer damages and the warranty becomes void.

Any other operation may lead to dangers like short-circuit, burns, electric shock, etc.

You endanger your own safety and the safety of others!

Improper installation can cause serious injuries and damage of property!



D-100/H-100



Return Procedure



Returned merchandise must be sent prepaid and in the original packing, call tags will not be issued. Package must be clearly labeled with a Return Authorization Number (RMA number). Products returned without an RMA number will be refused. Highlite will not accept the returned goods or any responsibility. Call Highlite 0031-455667723 or mail aftersales@highlite.nl and request an RMA prior to shipping the fixture. Be prepared to provide the model number, serial number and a brief description of the cause for the return. Be sure to properly pack fixture, any shipping damage resulting from inadequate packaging is the customer's responsibility. Highlite reserves the right to use its own discretion to repair or replace product(s). As a suggestion, proper UPS packing or double-boxing is always a safe method to use.

Note: If you are given an RMA number, please include the following information on a piece of paper inside the box:

- 01) Your name
- 02) Your address
- 03) Your phone number
- 04) A brief description of the symptoms

Claims

The client has the obligation to check the delivered goods immediately upon delivery for any short-comings and/or visible defects, or perform this check after our announcement that the goods are at their disposal. Damage incurred in shipping is the responsibility of the shipper; therefore the damage must be reported to the carrier upon receipt of merchandise.

It is the customer's responsibility to notify and submit claims with the shipper in the event that a fixture is damaged due to shipping. Transportation damage has to be reported to us within one day after receipt of the delivery.

Any return shipment has to be made post-paid at all times. Return shipments must be accompanied with a letter defining the reason for return shipment. Non-prepaid return shipments will be refused, unless otherwise agreed in writing.

Complaints against us must be made known in writing or by fax within 10 working days after receipt of the invoice. After this period complaints will not be handled anymore.

Complaints will only then be considered if the client has so far complied with all parts of the agreement, regardless of the agreement of which the obligation is resulting.



Description of the device

Features

Combine the D-100 (D6547D) and the H-100 (D6547H) to create a powerful horn loudspeaker.

Driver (D6547D)

Input voltage: 100V AC, 50/60 Hz
Power consumption: 100W
Frequency response: 150~6 kHz
Sensitivity (1W/1M): 100 dB

Power taps: 50W/100WHousing: Aluminum

• IP rating: IP66

• Dimensions: 145 x 145 x 173 mm (LxWxH)

• Weight: 3,9 kg

Horn (D6547H)

• Material: Aluminum

• Dimensions: 515 x 515 x 370 mm (LxWxH)

Weight: 1,9 kg



Please note that you need to purchase **both**, the D-100 **(D6547D)** and the H-100 **(D6547H)**, to create your horn loudspeaker.



Installation

Assembly

Connect all the elements in the order presented below.




Fig. 01

- 01) M10 x 20 mm hexagon head screw
- 02) Ø10 x Ø25 x 1,5 mm washer
- 03) Supporting bracket
- 04) Ø10 x Ø30 x 2 mm rubber washer
- 05) Mounting bracket
- 06) Ø10 x Ø25 x 1,5 mm washer
- 07) Ø10 x Ø18 x 2 mm spring washer
- 08) Butterfly nut







Fig. 02

- 09) Ø6 x Ø20 x 1,5 mm washer
- 10) M5 x 14 mm hexagon head screw
- 11) Ø20,5 x Ø32,5 x 2,5 rubber washer
- 12) Driver (D6547D)



Connecting To a PA Amplifier

01) Connect the speaker to the amp. Make sure that you connect the cables to the appropriate connectors. (The black cable = common, the green cable = 50W, the white cable = 100W).



Troubleshooting

No Sound

Always check if all the cables and cords are connected. Always turn off power to the area before checking the wires, to prevent electric shock.

If everything works properly and there is still no sound, revisit the manufacturer's instructions to make sure they were followed during installation. If everything was installed correctly and there is still no sound, you may want to consider bringing in a professional to take a look at your speakers.

Sound Warping

If the sound coming out of your loudspeaker is loud enough, but seems to be warped or distorted, your treble or bass levels may need to be adjusted.

Too much treble can make the sound bounce off of fixtures in the room, making it tinny sounding. With the bass, if the loudspeaker is too close to a wall and is not aimed properly, then you will need to set the bass to minus, to stop the low tones from bouncing off of the walls or large pieces of furniture.

Product Specification

Driver (D6547D)

Input voltage: 100V AC, 50/60 Hz

Power consumption: 100W
Frequency response: 150~6 kHz
Sensitivity (1W/1M): 100 dB
Power taps: 50W/100W
Housing: Aluminum

IP rating: IP66

Dimensions: 145 x 145 x 173 mm (LxWxH)

Weight: 3,9 kg

Horn (D6547H)

Material: Aluminum

Dimensions: 515 x 515 x 370 mm (LxWxH)

Weight: 1,9 kg


Design and product specifications are subject to change without prior notice.





Website: www.Dap-audio.info
Email: service@highlite.nl



Dimensions









Notes	



D-100/H-100



Ordercode: D6547D/D6547H



©2015 DAP Audio